

Terminating another cable in this box using SNAPCONNECT.

1. When terminating another cable in this box, remove the Plaster Ring Assembly from the mounted Universal Bracket. The box will remain attached to the bracket.
2. To install the AC-MC Cable Whip from the next Assembly remove the KO and snap the connector into the box.
3. Adjust the Cable Holder to the desired angle to install the AC-MC cable per National Electrical Code section 300.4(D). To attach the AC-MC cable, push the cable into the holder until it snaps in.
4. Terminate the appropriate conductors to the WAGO's (provided) coming from the SNAPCONNECT and reattach the Plaster Ring Assembly to the mounted Universal Bracket.

