

# Cable Holder – Installation Notes

Catalog Numbers: **CS1 For 16” Stud Space & CS2 For 24” Stud Space**

A product of Denier Manufacturing. 10891 State Route 128 Harrison, Ohio 45030  
1-800-286-9601 @ www.roughinready.com



1. Mount cable holder in position desired- see diagrams below.
2. Mount to wall and Stack with **AC-MC Cable**.
3. Fold **End Tabs** up.
4. Align Small Tabs to **Slots** in next cable support.
5. Fold **Small Tabs** over then insert screws.

Cat. No.	Size And Load Rating	Application
	Table-1 Size	
CS1	Up to ten MC cables Size 12-2 up to 10-4	MC Cable
CS2	Up to sixteen MC Cables Size 12-2 up to 10-4	MC Cable

